



## Important!

Due to size differences in dip stick tubes, when using an aftermarket oil pan you may need to replace the standard O-Rings and use the supplied replacement O-Rings. If the dipstick is loose and doesn't fit firmly in the tube on the oil pan use the two different O-rings supplied, the larger is fitted first to the top O-Ring recess and the smaller of the two is to be fitted last to the bottom O-Ring recess of the dip stick. This will ensure a leak free seal in aftermarket pans including Aeroflow replacement and super pans.



## Important!

Due to size differences in dip stick tubes, when using an aftermarket oil pan you may need to replace the standard O-Rings and use the supplied replacement O-Rings. If the dipstick is loose and doesn't fit firmly in the tube on the oil pan use the two different O-rings supplied, the larger is fitted first to the top O-Ring recess and the smaller of the two is to be fitted last to the bottom O-Ring recess of the dip stick. This will ensure a leak free seal in aftermarket pans including Aeroflow replacement and super pans.



## Important!

Due to size differences in dip stick tubes, when using an aftermarket oil pan you may need to replace the standard O-Rings and use the supplied replacement O-Rings. If the dipstick is loose and doesn't fit firmly in the tube on the oil pan use the two different O-rings supplied, the larger is fitted first to the top O-Ring recess and the smaller of the two is to be fitted last to the bottom O-Ring recess of the dip stick. This will ensure a leak free seal in aftermarket pans including Aeroflow replacement and super pans.